



REGULAR SERVICE PERIOD (1) Perform at every indicated month or operating hour interval, whichever comes first.		Each use	First month or 20 hrs.	Every 3 months or 50 hrs.	Every 6 months or 100 hrs.	Every year or 300 hrs.
ITEM						
Engine oil	A B	Check level Change	●	●	●	
Air cleaner	C D	Check Clean Replace	●	● (2)		● (3)
Sediment cup	E	Clean			●	
Spark plug	F	Check-adjust Replace			●	●
Spark arrester (applicable types)	G	Clean			● (*)	
Idle speed	H	Check-adjust				● (4)
Valve clearance	I J K	Check-adjust				● (4)
Combustion chamber	L	Clean	After every 500 hrs. (4)			
Fuel tank and filter	M	Clean			● (4)	
Fuel tube	N	Check	Every 2 years (Replace if necessary) (4)			

- (1) For commercial use, log hours of operation to determine proper maintenance intervals.  
 (2) Service more frequently when used in dusty areas. (3) Replace paper element type only.  
 (4) These items should be serviced by your servicing dealer, unless you have the proper tools and are mechanically proficient. Refer to Honda shop manual for servicing procedures.  
 (\*) In Europe and other countries where the machinery directive 2006/42/EC is enforced, this cleaning should be done by your servicing dealer.

